























Montážní návod


Komoda PIANO 1D3S - malá

ARTEN NÁBYTEK




- | | | | | |
|-------------------|-------------------|-------------------|-------------------|-------------------|
| ① 1x 859x402x18mm | ② 1x 695x400x18mm | ③ 1x 695x400x18mm | ④ 1x 695x380x18mm | ⑤ 1x 856x400x18mm |
| ⑥ 2x 408x100x18mm | ⑦ 1x 690x406x18mm | ⑧ 1x 408x399x18mm | ⑨ 1x 408x399x18mm | ⑩ 1x 137x399x18mm |
| ⑪ 1x 137x399x18mm | ⑫ 1x 393x375x18mm | ⑬ 3x 170x406x18mm | ⑭ 3x 355x110x18mm | ⑮ 3x 355x110x18mm |
| ⑯ 3x 345x110x18mm | ⑰ 3x 377x362x3mm | ⑱ 1x 727x432x3mm | ⑲ 1x 727x417x3mm | |


A  x 29	C₁  x 4	D  x 90	F₁  x 6	G  4x16 x 24	I  x 4	K₁  x 4	L₂  x 6	O  x 1	R  4x30 x 4
B  x 24	C₂  x 6	E  x 4	F₂  x 6	H  3,5x16 x 32	J  x 1	L₁  x 6	N  x 4	P  3x12 x 8	S  x 7




4



5



6



7

